

CONNECTOR DIAGRAM
 36 - PIN BLOCK
 NOT TO SCALE

	B	A	
PARK	12	0	GND
RF +	11	0	RR +
RF -	10	0	RR -
LR -	9	0	LF -
LR +	8	0	LF +
RU1 2	7	0	RU1 1
AMP MUTE	6	0	RU1 REF OUT
N/C	5	0	ANT GND
DIM +	4	0	FM DET +
SW 12V OUT	3	0	RSA ENABLE
IGN12V	2	0	CLASS 2 B
BATT12V	1	0	CLASS 2 A
N/C *	FG	0	CL2 RMT
N/C *	EH	0	R AUX IN
N/C *	DJ	0	L AUX IN
AUXSHIELD	CK	0	AUX COM
N/C *	BL	0	AUX MONO -
AUX MONO ENABLE	AM	0	AUX MONO +

* THESE PINS ARE INTERNALLY GROUNDED
 AND ARE NOT TO BE USED FOR ANY
 EXTERNAL CONNECTIONS

