


+ 5 V/Brown



The Infill G4 supports 6 bottoms.

Each resistor has to be of different value.

When measuring with an instrument there must not be any value across ground and +5 V/Brown

When using the Infill G4 steering wheel configuration tool push the bottom for that action and the tool designate a key for this I.e. ALT +D2